


## User Manual: Enabling AWDL (AirPlay P2P) Mode

### Device: EZCast Pro Dongle II (D15) and EZCast Pro Box II (B11)

This guide provides step-by-step instructions for activating Apple Wireless Direct Link (AWDL) to enable peer-to-peer AirPlay or Miracast connections. Please note that only one source device is supported at a time and Google Cast (Chromecast) is not supported in this mode.

#### Step 1: Connect to the Device Wi-Fi

1. Power on your **EZCast Pro Dongle II** and wait for the Home Page to appear on your display.
2. Locate the **SSID** (Network Name) and **Password** displayed at the top of the Home Page.
3. On your computer or mobile device, open Wi-Fi settings and connect to the SSID.






## Step 2: Access the Web Setting Interface


1. Once connected, look at the **bottom-left corner** of the TV/Monitor screen to find the **IP Address**.
2. Open a web browser (such as Chrome or Safari) on your connected device.
3. Type the IP address into the browser's address bar and press Enter to log into the **Web Setting** dashboard.

## Step 3: Enable AirPlay P2P (AWDL)

1. Scroll down the Web Setting page until you find the **AirPlay P2P** section.
2. Toggle the switch to **Enable** or **On**.
3. The device will now support AWDL, allowing devices to discover and cast via AirPlay/Miracast without needing a shared infrastructure Wi-Fi network.



- Once enabled, the device will reboot, and the landing page will appear as below. You can then begin using Miracast/AirPlay P2P mirroring.





## Reverting to Original AP Mode

- **To return to the original mode (AP Mode):** Simply disconnect the power from the EZCast Pro Dongle II (D15) or EZCast Pro Box II (B11) and plug it back in.
- The device will perform a cold boot and automatically revert to its default **Access Point (AP) Mode**.